
xionel 享能

物料编码(material code) :

210MM

140MM

USER MANUAL




Thank you for purchasing our product, in order to use this product safely, please read the instructions carefully before use, and keep this manual for future reference.

I -01 ENG

■Schematic:

①Output(Type-C) ②Output Cable(Type-C) ③Input(Type-C) ④Silicon Cover
Battery Indicator ⑥Switch Button ⑦Zinc Alloy Bracket



I -02 ENG

■Product Specification:

●Product Model: M1
●Input(Type-C): 5V⎓2A
●Output Cable(Type-C): 5V⎓2.1A
●Working Temperature: 0℃-50℃
●Product Weight: ≈90g
●Battery Type: Rechargeable Li-Ion Polymer Cell
●Output(Type-C): 5V⎓2.1A
●Charging Time: About 2.5 hours(Use PD 10W adapter)
●Product Size: (L)81.5×(W)48×(H)27.5(mm)

■Instructions:

1. Short press the button once display the remaining power

The 4 Led indicators respectively shows the battery status as below:

Indicator light: ON OFF	Battery capacity
○ ○ ○ ○	0%
● ○ ○ ○	1%-25%
● ● ○ ○	25%-50%
● ● ● ○	50%-75%
● ● ● ●	75%-100%

2. How to use the zinc alloy bracket

The built-in zinc alloy bracket of the mobile power will be snapped up with your fingers, and you can rotate the angle of the bracket according to your needs, no matter your cell phone is placed vertically or horizontally, it will play a solid support role.




I -03 ENG

2. Charge the power bank through phone adapter

This power bank has one Type-C input port, connect the charge cable with the phone power adapter, you can charge for this power bank. During the charging process, LED indicators flash, when full charged, the 4 LED indicators keep on.

⚠ **Please Note:**
If swells or liquid leakage phenomenon occurs during working, stop using it immediately.



Type-C Input

I -04 ENG

4. Charge for cell phones, iPad and other digital products

The power bank has one Type-c output port, builtin one Type-C output cable, connect the digital product with the output port, it can charge for the digital product, during the charging process, LED indicators light up. When the digital device is full charged, please stop supplying power to the digital device, then the LED indicator turns off.

⚠ **Please Note:**
When the power remaining is low, the battery indicator flash for warning, the device can`t output at this moment.



Type-C Output　　Type-C cable Output

I -05 ENG

■Please Attention

●Full charge the product with your first time use;
●If swell, leakage, deformation, immerse in water, short circuit occurs, stop using immediately;
●Don`t drop the device or use it in the high temperature, moist, strong magnetic environment;
●Please put the power bank on the place where kids can`t reach;
●Don`t leave the product on the car dashboard, the high temperature will damage the device cause by strong sunlight irradiation;
●Don`t throw any debris in the input output ports, it may cause damaged or short circuit;
●Avoid the unusual results happen, please use the standard or original packaged charging cable, power adapter etc.;
●Don`t use the all in one cable to charge multi devices simultaneously, it may cause damage to the power bank;
●Please confirm whether you device input voltage is the same with the power bank`s output voltage before charging;
●Over discharge may occur if long time lay aside, in order to not affect the performance, please full charge and discharge the power bank at least every 3 months.

■Warning:


●The device include Li-ion battery cell, don`t disassemble the power bank`s shell without permission, may cause the cell damaged or other danger;
●Don`t disassemble, press, puncture or make it short circuit, don`t throw into water, fire or exposed outside that above 60℃, to avoid catching fire and other danger;
●The device has over heat protection, it will stop working when the environment`s temperature exceed the normal condition, you should put it in the normal environment, then restore it`s output by short press the button.

I -06 ENG

210MM

140MM

使用说明书




感谢您购买我们的产品，为了您能安全使用本产品，请在使用前仔细阅读说明书，请保管此说明书以备将来使用。

I -01 CHN

■产品标识图:

①输出(Type-C) ②输出线(Type-C) ③输入(Type-C) ④硅胶盖子
⑤电量指示灯 ⑥开关按键 ⑦锌合金支撑架



I -02 CHN

■产品规格:

●产品型号: M1
●输入(Type-C): 5V⎓2A
●输出线(Type-C): 5V⎓2.1A
●工作温度: 0℃-50℃
●产品重量: ≈90g
●电芯类型: 可充电锂离子电芯
●输出(Type-C): 5V⎓2.1A
●充满时间: 大概2.5小时充满(使用10W充电器)
●L(81.5×(W)48×(H)27.5(mm)

■使用说明:

1. 单次短按开关显示移动电源剩余电量

4颗LED电量指示灯分别表示电池容量状态如下:

电量指示灯: 开 关	电池剩余容量
○ ○ ○ ○	0%
● ○ ○ ○	1%-25%
● ● ○ ○	25%-50%
● ● ● ○	50%-75%
● ● ● ●	75%-100%

2.转盒支架使用方法

将移动电源闭置背在支架用手指扣起，可以根据自己需要旋转支架角度，不管您的手机竖放横放都起到稳固的支撑作用。




I -03 CHN

3. 使用电源适配器给本移动电源充电

移动电源搭载1个Type-C输入端口，通过数据线链连接您手机电源适配器给本移动电源进行蓄电，移动电源蓄电过程中LED电量指示灯闪烁，蓄满电后4颗LED电量指示灯常亮。

⚠ **注意:**
如果在使用中发现产品鼓包或者漏液等不良现象，请立即停止使用。




Type-C 输入

I -04 CHN

4.给手机, 平板电脑等数码产品供电

本移动电源搭载1个Type-c输出接头，内置1根Type-C输出线缆，将输出端连接数码产品对数码产品进行充电，充电过程中，移动电源LED电量指示灯亮起，当数码产品充满电后，请停止给数码设备供电，LED电量指示灯熄灭。

⚠ **注意:**
当本移动电源电量过低，电量指示灯报警闪烁，此时不能进行供电输出。



Type-C 接口输出　　Type-C 输出线

I -05 CHN

■注意事项:

●首次使用, 请先将本产品充满电;
●若本产品存在电池膨胀、漏液、变形、浸水或短路等 异常时, 请立即停止使用;
●请勿放落或在高温、潮湿、强磁等环境下使用本产品;
●请将本产品放置在儿童不能接触的地方;
●勿将此产品遗放在汽车中, 强阳光照射的车内高温会导致此产品损坏;
●勿将任何异物置入产品的输入输出孔位, 以免造成短路或损坏;
●为避免本产品使用出现异常, 请使用合格或者手机配套的充电线, 电源适配器等配件;
●请勿使用多合一的数据线同时对多台设备进行充电, 防止对设备造成损坏;
●在您的设备充电前, 请确认设备输入电压是否和移动电源输出电压相符;
●移动电源如果长时间不使用, 可能会出现过放电, 为不影响移动电源的性能, 请至少每3个月对移动电源进行一次完全的充放电。

■警告:

●本产品包含锂离子电芯, 严禁私自拆开产品外壳, 避免可能造成的电芯破损或其他危险;
●严禁随意拆解, 挤压, 穿刺, 短路本产品, 或投入水, 火中或暴露于温度高于60℃的环境中, 以免引起火灾等危险;
●本产品内置过温保护功能, 当使用环境温度超过正常使用温度范围时可能会出现过温保护现象, 此时只需将产品移至常使用温度环境下, 单击按键即可恢复输出。

I -06 CHN

设计(design):何悦霞
审核(check):谢琼斌
批准(approve):
版本(version):V1.00

数量(quantity):
单位(units):PCS
比例(scale):1:1
页数(page):

产品型号(model):M1（中性共用）
产品名称(name):中英文说明书
包装类型(type):风琴折页
设计日期(date):2023.09.11

颜色(colour):拼版印刷
尺寸(size):如上图
材料(materia):80g单铜
表面处理(surface finish):哑面

广东享能电子有限公司
GuangDong Xionel Electronic Co., Ltd
深圳市龙华区龙华街道富康社区旭日小区3-5栋旭日大厦11层
0755-2376 9185
robin.xie@xionel.com.cn